



Instructions: Fog Features for Barge Navigation Lights

First Use:

- Open back cover of remote
- Insert two (2) new AA batteries in the correct orientation (red dots mark the positive side)
- Close back cover
- Screw included antenna onto top as shown to the right
- Press button on front to test remote

Normal Usage:

- Press button and release
- Red activity LED lights up when transmitting
- If LED does not light, replace batteries
- BGLED-FOG lights react within 6 seconds with good signal
- Lights will turn on even if it is daytime
- Range of up to 1000 feet line of sight
- Range is reduced by obstructions such as walls, buildings, and metal structures

TXH-RC-ANT-FOG Wireless Transmitter



BGLED-FOG Barge Navigation Lights



First Use:

- Open case and connect fuse inside
- Close case
- Move switch to "ON" position
- Ready to deploy

Fog Feature without Remote:

- Move switch to "OFF" position
- Wait 2 seconds
- Move switch to "ON" position
- Light should come on even if it is daytime

